

# Centrifugal Water Chillers

## Model CVGF

Water-Cooled Hermetic Centrifugal Refrigeration Capacities from 400 to 1000 Tons (1400~3510 kW) 50 and 60 Hz



October 2008

CTV-PRC001-E4



## Introduction

#### Introducing Trane's Model CVGF Centrifugal Water Chiller

Introduction

The basic gear driven centrifugal water chiller design was introduced in 1976 and has been proven in thousands of installations. Trane continues to deliver its reliability and energy fitness commitment on its newest line of gear-drive centrifugal water chillers, the Model CVGF. The major advantages of the Model CVGF are:

- High reliability
- Low sound levels
- Compact size
- High efficiency at a competitive market price
- Designed to use environmentally responsible HFC-134a refrigerant

The Model CVGF chiller is ideal for office, hospital, school, hotel, retail store and industrial buildings. TheTrane centrifugal chiller line offers hundreds of individual evaporator-condensercompressor combination selections, permitting precise tailoring of the machine capacity to system requirements. Machine selections can be computer optimized to provide low first cost, low operating cost, or other criteria important for a particular selection. Centrifugal Water Chiller computer selection program is certified in accordance with ARI Standard 550/590. Trane Sales Engineers are available to assist in selecting the optimum machine to satisfy the particular project requirements.

Turn to the Model CVGF for energy efficiency provided by the two stage, gear drive centrifugal water chillers with economizers. The Trane Model CVGF is your choice for energy fit operation year after year.



## Contents

Introduction2
Features and Benefits9
Application Considerations10
General Data ······12
Jobsite Connections 13
Controls17
Physical Dimensions 19
Mechanical Specifications23
Conversion Table 27



## **Features and Benefits**

#### Standard CVGF Features

The following features are provided as standard with all Trane Model CVGFchillers:

- Hermetic two-stage centrifugal compressor-motor assembly with integral lubrication system and economizer cycle
- Evaporator and condenser assembly
- Prewired instrument and control panel
- Oil charge
- Integral oil heaters
- Isolation pads
- Wiring and oil system interconnection to main control panel
- Advance motor protection
- Two-stage gear drive with economized cycle for high efficiency and high reliability
- Liquid cooled hermetic induction motor; the motor operates at lower temperatures for longer motor life

#### **Optional Features**

- Unit and remote wye-delta mounted starters
- Unit mounted, floor mounted, and wall mounted solid state starters.
- Across-the-line, Primary Reactor, and Auto Transformer Remote mounted starter for medium/ high voltage
- Marine waterboxes for evaporator and condenser
- Factory-applied thermal insulation
- One-inch deflection spring isolators for vibration-sensitive installations
- Refrigerant available from a local distributor
- Building automation systems (BAS) Interface
- Factory testing

#### Applications

- Comfort cooling
- Industrial process cooling

#### Patents

- Polygon drive for refrigeration compressor impellers
- Centrifugal compressor sump demister
- Internal oil filter
- Thermosiphonic oil cooler
- Compressor height and alignment adjustment
- Oil return using hot gas for motive force
- Centrifugal impeller assembly
- Internal oil filter

#### **Orifice System**

• Simplified orifice system with improved part load performance down to 20 percent part load



#### Advanced Heat Transfer Surfaces

- Evaporator and condenser tubes use the latest heat transfer surfaces
- Less refrigerant needed due to advanced patented evaporator design

#### **Compact Size**

- Designed with the retrofit and replacement market in mind
- The 400 to 500 NTON sizes can fit through most double-width doors
- Small footprint of the CVGF chiller saves valuable equipment room space

#### Simple Installation

- Simplified piping; the only water piping required is for the evaporator and condenser
- Simple power connection
- Unit mounted starter eliminates additional jobsite labor requirements

#### **Environmental Features and Benefits**

#### Improved Efficiency:

- High Efficiency: 0.55 kW/Ton at ARI conditions
- Motor cooling vented to economizer cycle, efficiency advantage
- HFC-134 optimized inlet guide vanes and impellers for improved cycle efficiency using computational fluid dynamics

#### **Reduced Emissions:**

- Over 30 percent joint reduction in compressor/motor assembly compared to previous designs
- Patented integral heaters imbedded into the compressor casting, no seals no leaks
- Beaded flat gasket technology instead of O-rings, lower susceptibility to developing leaks
- Minimal NPT pipe threads on chiller system, SAE O-ring boss fitting, lowerleak potential
- Oil sump internal to compressor/motor assembly with internal pump/motor; eliminates vent and drain lines, leak prevention
- Patented internal oil filter prevents leaks and contamination from pipes; filter is isolated and easily replaced
- Advanced evaporator design minimizes the refrigerant charge; a reduced charge reduces the exposure to the environment in the event of a catastrophic charge loss

#### Additional Features and Benefits

- Patented polygon attachment instead of a keyed shaft, self-balancing
- Easy to replace motor terminals
- Motor/stator assembly is easily removed; speed assembly can be removed independent of the high-speed assembly
- Rolling element bearings
- Hydrodynamic bearings
- Advanced evaporator design: no eliminator necessary with an advanced suction baffle design
- All metric fasteners



#### Features and Benefits

#### Tracer AdaptiView<sup>™</sup> Control Operator Interface

Tracer AdaptiView<sup>™</sup> control is the unit-mounted operator interface with a touch sensitive 12/1" display. The display presents information through an intuitive navigation system. Alternate languages are also available for the control panel display.

Tracer AdaptiView<sup>™</sup> control receives information from and communicates information to the other devices on the chiller's communications link. Tracer AdaptiView<sup>™</sup> control performs the Leaving Chilled Water Temperature and Limit Control algorithms.

- Data graphs
- Mode overrides
- Status (all subsystems) with animated graphics
- Auto/Stop commands
- 50 diagnostics
- ASHRAE chiller log
- Setpoint adjustment (daily user points)

Tracer AdaptiView<sup>TM</sup> control can be connected to the service tool using a standard USB type cable. The connections is located on the side of the control panel, along with a power outlet for a laptop PC power supply.



a At-a-glance status

On highly-readable color display showing key operating parameters of major chiller components

- Intuitive navigation Helps operators access data and alarms for quick and accurate response and resolution
- C Reports
- Summarize data for clear understanding and interpretation G Graphs
- Visualize trend data for troubleshooting and fine-tuning
   Adaptive control<sup>™</sup>
- Algorithms built into Tracer Adaptiview<sup>™</sup> pre-empt chiller disruptions during rapidly changing conditions
- Open protocol flexibility Bacnet, Lontalk, and Modbus with no gateways
- Adjustable viewing angle
   For all operators in close quarters via ergonomic arm
- Water-resistant To cleaning overspray; weather-resistant for outdoor mounting with optional cover
- Security levels
- Limit access to designated, qualified staff members
- 24 selectable languages Convert the Tracer Adaptiview<sup>™</sup> user-centered design for global deployment including simplified chinese, traditional chinese, japanese, korean, thai, etc.



#### **Tracer TU Interface**

The Tracer chiller controller adds a level of sophistication better served by a PC application to improve service technician effectiveness and minimize chiller downtime. Tracer AdaptiView<sup>™</sup> control is intended to serve only typical daily tasks. The portable PC-based service-tool software, Tracer TU<sup>™</sup>, supports service and maintenance tasks.

Tracer TU serves as a common interface to all Trane chillers, and will customize itself based on the properties of the chiller with which it is communicating. Thus, the service technician learns only one service interface.

The panel bus is easy to troubleshoot using LED sensor verification. Only the defective device is replaced. Tracer TU can communicate with individual devices or groups of devices.

All chiller status, machine configuration settings, customizable limits, and up to 100 active or historic diagnostics are displayed through the service-tool software interface.

LEDs and their respective Tracer TU indicators visually confirm the availability of each connected sensor, relay, and actuator.

Tracer TU is designed to run on a customer's laptop, connected to the AdaptiView control panel with a USB cable.

Hardware requirements for Tracer TU:

- CD-ROM
- 1 GB RAM
- 1024 x 768 resolution
- Ethernet 10/100 Lan card
- Windows® XP Pro or Vista
- Pentium IV or higher processor
- An available USB port (USB 2.0)

	1. Unit Summary 2. Unit Status 3. Alar	<u>ms</u>	4. Controller Status	
e Tree	СТV		Current Mode : Stopped	
Сту	Model: Tracer UC800 @ CenTraVac @ Build		I Immediate Shutdown 44 Active Alarma False False	
	Evaporator	*	R Setpoints	
	38.0 °F Active Chiller Water Setpoint		38 *F Fiont Panel Chilled Water Setpoint	
	Entering Water Temperature		Front Panel V Setpoint Source	
	Leaving Water Temperature			
	Saturated Refrigerant Temperature		42 28LA Fiont Panel Current Limit Setpoint	
	Off Water Pump [Control]			
	WaterFlow Switch Status		Motor R	
	Condenser	*	42.02 Active Current Limit Setpoint	
	Entering Water Temperature		Average Line Current	
	Leaving Water Temperature		Stater Current L1	
	Saturated Refrigerant Temperature		Starter Current L1	
	Befrigerant Pressure		Starter Current L2	
			Stater Current L3	
	Approach Temperature		Stater Current L3	1 88



#### Features and Benefits

#### Tracer AdaptiView<sup>™</sup> Controller

Today's centrifugal chillers offer predictive controls that anticipate and compensate for load changes. Other control strategies made possible with the Tracer AdaptiView™ controls are:

#### Feedforward Adaptive Control

Feedforward is an open-loop, predictive control strategy designed to anticipate and compensate for load changes. It uses evaporator entering-water temperature as an indication of load change. This allows the controller to respond faster and maintain stable leaving-water temperatures.

#### Soft Loading

The chiller controller uses soft loading except during manual operation. Large adjustments due to load or setpoint changes are made gradually, preventing the compressor from cycling unnecessarily. It does this by internally filtering the setpoints to avoid reaching the differential-to-stop or the current limit. Soft loading applies to the leaving chilled-water temperature and current-limit setpoints.

#### **Multi-Objective Limit Arbitration**

There are many objectives that the controller must meet, but it cannot satisfy more than one objective at a time. Typically, the controller's primary objective is to maintain the evaporator leaving-water temperature.

Whenever the controller senses that it can no longer meet its primary objective without triggering a protective shutdown, it focuses on the most critical secondary objective. When the secondary objective is no longer critical, the controller reverts to its primary objective.

#### Fast Restart

The controller allows the CenTravac chiller to restart during the postlube process. If the chiller shuts down on a nonlatching diagnostic, the diagnostic has 30–60 seconds to clear itself and initiate a fast restart. This includes momentary power losses.

#### **Building Automation and Chiller Plant Control**

Trane Tracer Summit<sup>TM</sup> building automation systems include pre-engineered and flexible control for chiller plants. It can control the operation of the complete installation: chillers, pumps, cooling towers, isolating valves, air handlers and terminal units.Trane can undertake full responsibility for an optimized automation and energy management for the entire chiller plant.

The main functions are:

- Chiller sequencing: equalizes the number of running hours of the chillers. Different control strategies are available depending on the configuration of the installation.
- Control of the auxiliaries: includes input/output modules to control the operation of the various auxiliary equipments (water pumps, valves, cooling towers, etc.)





- **Time of day scheduling:** allows the end user to define the occupancy period, i.e. time of the day, holiday periods and exception schedules.
- Optimization of the start/stop time of the installation: based on the programmed schedule of occupancy and on the historical temperature records, Tracer Summit<sup>™</sup> calculates the optimal start/stop time of the installation to get the best compromise between energy savings and comfort of the occupants.
- **Soft loading:** the soft loading function minimizes the number of chillers that are operated to satisfy a large chilled-water-loop pull down, thus preventing an overshoot of the actual capacity required. Unnecessary starts are avoided and the peak current demand is lowered.
- Communication capabilities: local, through a PC workstation keyboard Tracer Summit<sup>™</sup> can be programmed to send messages to local or remote workstations and or a pager in the following cases:
  - -Analog parameter exceeding a programmed value.
  - -Maintenance warning.
  - -Component failure alarm.
  - —Critical alarm messages. In this latter case, the message is displayed until the operator acknowledges the receipt of the information. From the remote station it is also possible to access and modify the chiller plant's control parameters.
- **Remote communication through a modem:** As an option, a modem can be connected to communicate the plant operation parameters through voice grade phone lines.

The remote terminal is a PC workstation equipped with a modern and software to display the remote plant parameters.

#### **Chiller-Tower Optimization**

Tracer Summit<sup>™</sup> chiller-tower optimization extends Adaptive Control<sup>™</sup> to the rest of the chiller plant. Chiller-tower optimization is a unique control algorithm for managing the chiller and cooling-tower subsystem. It considers the chiller load and real-time ambient conditions, then optimizes the tower setpoint temperature to maximize the efficiency of the subsystem.

#### Integrated Comfort<sup>™</sup> System (ICS)

The onboard Tracer chiller controller is designed to be able to communicate with a wide range of building automation systems. To take full advantage of the capabilities of the chiller, incorporate your chiller into a Tracer Summit building automation system.

But the benefits do not stop at the chiller plant. At Trane, we realize that all energy used in your cooling system is important. That is why we worked closely with other equipment manufacturers to predict the energy required by the entire system. We used this information to create patented control logic for optimizing the HVAC system efficiency.

The building owner's challenge is to tie components and applications expertise into a single reliable system that provides maximum comfort, control and efficiency. Trane's Integrated-Comfort <sup>™</sup> Systems (ICS) are a concept that combines system components, controls and engineering applications expertise into a single, logical and efficient system. These advanced controls are fully commissioned and available on every piece of Trane equipment, from the largest chiller to the smallest VAV box. As a manufacturer, only Trane offers this universe of equipment, controls and factory installation and verification.




#### Two-Stage Compressor Widens the Application Range

#### Why Centrifugal Compressors Surge

Centrifugal compressors produce their pressure differential (head) by converting the kinetic energy of the gas leaving the impeller into static pressure. The velocity of this gas is the result of two components:

- The radial velocity component V<sub>n</sub>, which is directly proportional to the refrigerant gas flow Q.
- The tangential velocity component Vt, which is a function of both impeller diameter D and the rotational speed rpm.

The length of the resultant vector V is proportional to the kinetic energy available for conversion to static pressure in the volute. Consequently, for a given compressor, Vt is fixed and  $V_r$  varies with the cooling load. With the chiller unloading, the pressure differential between evaporator and



condenser decreases. The compressor matches the new load and the lower "head" by closing the inlet guide vanes.

This reduces the gas flow it draws in and modifies its direction. Component  $V_r$  decreases accordingly, the vector diagram shifts and at some point, the balance of forces breaks down.


As pressurized gas rushes backwards through the impeller, the pressure in the gas passages falls, allowing the compressor to restore the balance of forces. If the process repeats itself, the compressor is said to surge.

#### Two-Stage Compressors Surge Less and Later


To produce the same head as a single-stage compressor, two-stage machines use two small diameter impellers. Component Vt is the same as on each stage, though Vr is the same as on a single-stage compressor. This results in a better balance of forces at low loads and produces a machine with a wider unloading capability.

In Trane centrifugal chillers, gas prerotation vanes ahead of the compression stage improve impeller aerodynamic efficiency, resulting in smoother unloading and reducing power consumption.

The curves show that two-stage compressors surge less and later than single-stage machines. Intersection point B, when the load line meets the surge area, corresponds to a higher part load for the single-stage compressor than would be the case with a two-stage compressor. Two stage machines, therefore, have a wider range of applications.



Typical single-stage compresso performance curve



4 - B 5 - 20% 6 - 90° 7 - 80°

2 - Surge Line

3 - A

- 8 70° Vanes
- 9 100%
- 10 Compressor Head

11 - Refrigerant Gas Flow

Typical two-stage compressor performance curve



## **Application Considerations**

#### **Condenser Water Limitations**

Condenser water	Limitations
Temperature	
	Trane centrifugal chillers start and operate over a range of load conditions with controlled water temperatures. Reducing the condenser water temperature is an effective method of lowering the chiller power input. However, the effect of lowering the condenser water temperature may cause an increase in system power consumption.
	In many applications Trane centrifugal chillers can start and operate without control of the condenser water temperature. However, for optimum system power consumption, and for any applications with multiple chillers, control of the condenser water circuit is recommended. Integrated control of the chillers, pumps, and towers is easily accomplished with Trane's AdaptiView and/or Tracer system.
	Chillers are designed to ARI conditions of 29.4°C (85°F), but Trane centrifugal chillers can operate to a five psig pressure differential between the condenser and evaporator at any steady state load without oil loss, oil return, motor cooling, or refrigerant hang-up problems. And this differential can equate to safe minimum entering condenser water temperatures at or below 12.8°C (55°F), dependent on a variety of factors such as load, leaving evaporator temperature, and component combinations. Startup below this differential is possible as well, especially with AdaptiView soft start features
Water Pumps	
	Avoid specifying or using 3600-rpm condenser and chilled water pumps. Such pumps may operate with objectionable noises and vibrations. In addition, a low frequency beat may occur due to the slight difference in operating rpm between water pumps and centrifugal motors. Where noise and vibration-free operation are important, Trane encourages the use of 1750 rpm pumps.
Water Flow	
	Today's technology challenges ARI's traditional design of three gpm per ton through the condenser. Reduced condenser flows are a simple and effective way to reduce both first and operating costs for the entire chiller plant. This design strategy will require more effort from the chiller, but pump and tower savings will typically offset any penalty. This is especially true when the plant is partially loaded or condenser relief is available.
	In new systems, the benefits can include dramatic savings with: • Size and cost for condenser lines and valves • Size and cost of the cooling tower • Size and cost of the water pumps • Pump energy (30% to 35% reduction) • Tower fan energy(30% to 35% reduction)
	Replacement chiller plants can reap even greater benefits from low-flow condensers. Because the water lines and tower are already in place, reduced flows would offer a tremendous energy advantage. Theoretically, a 2 gpm/ton design applied to a system that originally used 3 gpm/ton would offer a 70% reduction in pump energy. At the same time, the original tower would require a nozzle change but would then be able to produce about two degrees colder condenser water than before. These two benefits would typically offset any extra effort required by the chiller.



### **Application Considerations**

Contact your local Trane Sales Office for information regarding optimum condenser water temperatures and flow rates for a specific application.

#### Water Treatment

The use of untreated or improperly treated water in a chiller may result in scaling, erosion, corrosion, algae, or slime. It is recommended that the services of a qualified water treatment specialist are used to determine what treatment, if any, is advisable. Trane assumes no responsibility for the results of untreated or improperly treated water.



#### Table GD-1 – Model CVGF Description

Model		200011000		CVGF			
Nominal Cooling C	apacity						
Ũ	NTON	400	500	500	650	800	1000
Heat Exchanger Siz	ze						
Evaporator	EVSZ	500	500	700	700	1000	1000
Condenser	CDSZ	500	500	700	700	1000	1000
Heat Exchanger Bu	undles						
Evaporator	EVBS	A = Small	A = Small	A = Small	A = Small	A = Small	A = Small
		B = Medium	B = Medium	B = Medium	B = Medium	B = Medium	B = Medium
		C = Large	C = Large	C = Large	C = Large	C = Large D = Extra Large	C = Large D = Extra Large
Condenser	CDBS	A = Small	A = Small	A = Small	A = Small	A = Small	A = Small
		B = Medium	B = Medium	B = Medium	B = Medium	B = Medium	B = Medium
		C = Large	C = Large	C = Large	C = Large	C = Large D = Extra Large	C = Large D = Extra Large
Heat Exchanger Tu	ibe						
Evaporator	EVTM		IE25 - 0.635 mm	n W 25.4 mm Inter	nally Enhanced		
			(IE25 - 0.025" W	1.00" Internally E	nhanced)		
			TE25 - 0.635 mr	m W19 mm Interna	ally Enhanced		
			(TE25 - 0.025" V	V 0.75" Internally E	Enhanced)		
	CDTM			n W 25.4 mm Inter			
			(IE28 - 0.028" W	1.00" Internally E	nhanced)		
				m W 19 mm Intern	-		
			(TE28 - 0.028" V	V 0.75" Internally E	Enhanced)		
Evap/Cond Workin	g Pressure						
bar				10			
psi				150			
Evap/Cond Water (	Connection						
				oved Pipe Connec			
				anged Adaptor (IP			
			Fla	anged Adaptor (SI	Unit)		
Agency Approvals	(Chiller)						
				JL-CUL Listed/ASI			
			CE App	oroval/PED (Europe	ean Code)		
Motor Volt/Hz			000//00/				
				415/3300/6600 V			
			380/460/	575/3300/4160 Vo	011S – 60 HZ		
Starter*							
Unit Mounted		Mhie Delte Orticla		a, Solid-State Insid		tou *A. totuono (	
Remote Mounted		vvye-Delta, Solid-S	state inside the De	ata, "Across-the-lir	ie, "Primary Read	tor, *Autotransform	er

\*Medium Voltage (3300, 4160, 6600) Starter Types - Full Voltage (X-Line), Primary Reactor, Autotransformer

### Table GD-2 – Weight

					Without	t Starter			With S	Starter	
		Shell	Size	Oper	rating	Ship	ping	Oper	rating	Ship	ping
Model	Compressor	Evaporator	Condenser	lbs	kgs	lbs	kgs	lbs	kgs	lbs	kgs
CVGF	400 - 500	500	500	23288	10563	20570	9331	23856	10821	21142	9590
CVGF	500	700	700	28052	12725	24174	10965	28623	12984	24743	11223
CVGF	650	700	700	29508	13383	25635	11628	30105	13656	26058	11820
CVGF	800	1000	1000	40285	18273	34229	15526	40924	18563	34868	15816
CVGF	1000	1000	1000	41202	18689	35114	15941	41843	18980	35785	16232

\*\*Note: Values represent estimate maximum unit weights including shells with TECU tubes, max bundles, 2-pass evaporator and condenser, 150 psig non-marine waterboxes, and compressors with the largest low-voltage motors for each family.



### **General Data**

## 50 and 60 Hz SI Units and (English Units)

Table GD-3 –Evap	orator and	d Condens	ser Flow R	ates (Mini	mum and l	Maximum,	liters per	second, g	allons per	minute)
High Efficiency She	ells - 0.75 ind	ch (19 mm)	Internally E	nhanced C	u Tube:					
Condenser:										
Nominal Shell	500	500	500	700	700	700	1000	1000	1000	1000
Bundle Size	Small	Medium	Large	Small	Medium	Large	Small	Medium	Large	Extra Large
Number of Passes	2	2	2	2	2	2	2	2	2	2
Min Flow L/s (gpm)	31 (487)	34 (542)	37 (586)	42 (668)	47 (744)	52 (816)	59 (938)	67 (1056)	74 (1176)	77 (1213)
Max Flow L/s (gpm)	113 (1786)	125 (1987)	136 (2148)	155 (2450)	172 (2727)	189 (2993)	217 (3441)	244 (3874)	272 (4311)	280 (4447)
Evaporator:										
Nominal Shell	500	500	500	700	700	700	1000	1000	1000	1000
Bundle Size	Small	Medium	Large	Small	Medium	Large	Small	Medium	Large	Extra Large
Number of Passes	2	2	2	2	2	2	2	2	2	2
Min Flow L/s (gpm)	26 (407)	29 (458)	32 (511)	36 (566)	40 (628)	44 (698)	52 (822)	58 (921)	64 (1021)	72 (1136)
Max Flow L/s (gpm)	94 (1493)	106 (1680)	118 (1873)	131 (2077)	145 (2304)	161 (2559)	190 (3013)	213 (3377)	236 (3745)	263 (4165)
Evaporator:										
Nominal Shell	500	500	500	700	700	700	1000	1000	1000	1000
Bundle Size	Small	Medium	Large	Small	Medium	Large	Small	Medium	Large	Extra Large
Number of Passes	3	3	3	3	3	3	3	3	3	3
Min Flow L/s (gpm)	17 (271)	19 (305)	21 (340)	24 (378)	26 (419)	29 (465)	35 (548)	39 (614)	43 (681)	48 (757)
Max Flow L/s (gpm)	63 (995)	71 (1120)	79 (1248)	87 (1385)	97 (1536)	108 (1706)	127 (2009)	142 (2251)	158 (2497)	175 (2777)
Standard Efficiency	Shells - 1.0	00 inch (25.4	4 mm) Int. E	Enhanced C	u Tube:					
Condenser:										
Nominal Shell	500	500	500	700	700	700	1000	1000	1000	1000
Bundle Size	Small	Medium	Large	Small	Medium	Large	Small	Medium	Large	Extra Large
Number of Passes	2	2	2	2	2	2	2	2	2	2
Min Flow L/s (gpm)	31 (499)	35 (557)	38 (606)	43 (682)	48 (764)	53 (838)	58 (925)	64 (1020)	75 (1172)	83 (1307)
Max Flow L/s (gpm)	115 (1831)	129 (2041)	140 (2221)	158 (2501)	177 (2801)	194 (3071)	214 (3391)	236 (3741)	276 (4372)	302 (4792)
Evaporator:										
Nominal Shell	500	500	500	700	700	700	1000	1000	1000	1000
Bundle Size	Small	Medium	Large	Small	Medium	Large	Small	Medium	Large	Extra Large
Number of Passes	2	2	2	2	2	2	2	2	2	2
Min Flow L/s (gpm)	28 (447)	31 (496)	35 (550)	39 (625)	45 (706)	49 (784)	49 (781)	236 (3741)	63 (1003)	70 (1115)
Max Flow L/s (gpm)	103 (1638)	115 (1818)	127 (2018)	145 (2293)	181 (2874)	181 (2874)	181 (2864)	207 (3287)	232 (3678)	258 (4090)
Evaporator:										
Nominal Shell	500	500	500	700	700	700	1000	1000	1000	1000
Bundle Size	Small	Medium	Large	Small	Medium	Large	Small	Medium	Large	Extra Large
Number of Passes	3	3	3	3	3	3	3	3	3	3
Min Flow L/s (gpm)	19 (298)	21 (330)	23 (367)	26 (417)	30 (471)	33 (523)	33 ((521)	38 (598)	42 (669)	47 (744)
Max Flow L/s (gpm)	69 (1092)	76 (1212)	85 (1346)	96 (1529)	109 (1726)	121 (1916)	120 (1909)	138 (2191)	15 (2452)	172 (2726)




## **Jobsite Connections**

#### Supply and Motor Lead Wiring and Connections

Only copper conductors should be connected to the compressor motor due to the possibility of galvanic corrosion as a result of moisture if aluminum conductors are used. Copper conductors are recommended for supply leads in the starter panel.

Suggested starter panel line- and load-side lug sizes (when lugs are provided) are noted in the starter submittals. These submitted lug sizes should be carefully reviewed for compatibility with conductor sizes specified by the electrical engineer or contractor. If they are not compatible, the electrical engineer or contractor should specify the required lug sizes for the particular application. Ground lugs are provided in the motor terminal box and starter panel. The motor terminals are supplied with connection pads that will accommodate bus bars or standard terminal lugs (crimp type recommended). **Terminal lugs are field-supplied**. These connection pads provide additional surface area to minimize improper electrical connections. Also, a 3/8-inch bolt is provided on all connection pads for mounting the lugs. Figure J-1 illustrates the connection between the motor connection pads and the terminal lugs.

#### Figure J-1 — Electric Connections



#### Shipment and Assembly

All style hermetic centrifugal units ship as a factory assembled, factory tested package, ready to rig into place on factory supplied isolation pads.



**Standard Features** 

#### **Standard Features**

#### **Field Connection**

The field-connected elements are involved in physically turning the chiller on or off. This involves ensuring that the chiller is not in an emergency or external stop condition, starting the pumps, and verifying that flow has been established. The optional, factory-supplied flow switch or a customer-supplied differential-pressure switch can be used to prove flow.

#### Heat Exchanger Control

Fundamental internal variables that are necessary to control the chiller are gathered and acted upon by the heat exchanger control function.

#### Motor Control and Compressor Protection

This includes all functions that start, run, and stop the motor. The starter module provides the interface and control of Y-delta, across-the-line, primary reactor, autotransformer, and solid-state starters. The motor control also provides protection to both the motor and the compressor.

#### Phase Voltage Sensors - 3 phase

Includes factory-installed potential/current transformers in the starter for monitoring and displaying phase voltage and provides over/undervoltage protection. Tracer AdaptiView<sup>TM</sup> control, Tracer TU and Tracer Summit display the following:

- Compressor phase amperage (a-b, b-c, c-a)
- Kilowatts
- Power factor (uncorrected)
- Compressor-phase voltage (a-b, b-c, c-a)
- Kilowatt-hours

### **Chilled-Water Reset**

Chilled-water reset reduces energy consumption during periods of the year when heating loads are high and cooling loads are reduced. It is based on return chilled-water temperature. Resetting the chilled-water temperature reduces the amount of work that the compressor must do by increasing the evaporator refrigerant pressure. This increased evaporator pressure reduces the pressure differential the compressor must generate while in the heat recovery mode. Chilled-water reset is also used in combination with the hot-water control. By resetting the chilled-water temperature upward, the compressor can generate a higher condenser pressure, resulting in higher leaving hot-water temperatures.



**Optional Features** 

#### **Extended Operation Package**

Select the extended-operation package for chillers that require external, hot water control, and/or base-loading capabilities. This package also includes a 4-20 mA or 0-10 Vdc analog input for a refrigerant monitor.

- External base-loading control
- External base-loading relay
- External hot-water control relay
- Refrigerant monitor input

#### **Base-Loading Control**

This feature allows an external controller to directly modulate the capacity of the chiller. It is typically used in applications where virtually infinite sources of evaporator load and condenser capacity are available and it is desirable to control the loading of the chiller. Two examples are industrial process applications and cogeneration plants. Industrial process applications might use this feature to impose a specific load on the facility's electrical system. Cogeneration plants might use this feature to balance the system's heating, cooling, and electrical generation.

All chiller safeties and Adaptive Control functions are in full effect when Base Loading is enabled. If the chiller approaches full current, the evaporator temperature drops too low, or the condenser pressure rises too high, the controller's Adaptive Control logic limits the loading of the chiller to prevent the chiller from shutting down on a safety limit. These limits may prevent the chiller from reaching the load requested by the Base Loading signal.

An alternative and less radical approach to Base Loading indirectly controls chiller capacity. Artificially load the chiller by setting the chilled-water setpoint lower than it is capable of achieving. Then, modify the chiller's load by adjusting the current-limit setpoint. This approach provides greater safety and control stability because it leaves the chilled-water temperature-control logic in effect. The chilled-water temperature control responds more quickly to dramatic system changes and limits chiller loading prior to reaching an Adaptive Control limit.

#### **Hot-Water Control**

This feature allows an external controller to enable/disable and modulate the hot-water control mode. Occasionally, centrifugal chillers are used to provide heating as a primary mission. In this case the external controller or operator would select a hot-water temperature setpoint and the chiller capacity would be modulated to maintain the setpoint. Heating is the primary mission and cooling is a waste product or a secondary mission. This technique provides application flexibility, especially in multiple-chiller plants in conjunction with undersized heating plants.

The chiller needs only one condenser for hot-water control, whereas Heat Recovery uses a secondary condenser.

#### **Refrigerant Monitor**

The Extended Operation package allows for a refrigerant monitor to send a 4-20 mA signal to the Tracer AdaptiView<sup>™</sup> control display. It can be calibrated to correspond to either 0-100 ppm or 0-1,000 ppm concentration levels. The concentration level is displayed at Tracer AdaptiView<sup>™</sup> control, but the chiller will not take any action based on the input from the refrigerant monitor.

Alternatively, a refrigerant monitor can be connected to Tracer Summit, which has the ability to increase ventilation in the equipment room in response to high refrigerant concentrations.



#### **Standard Protections**

The chiller controller uses proportional-integral-derivative (PID) control for all limits—there is no dead band. This removes oscillation above and below setpoints and extends the capabilities of the chiller.

Some of the standard protection features of the chiller controller are described in this section. There are additional protection features not listed here. Contact your local Trane office for additional protection information.

#### **High Condenser-Pressure Protection**

The chiller controller's condenser limit keeps the condenser pressure under a specified maximum pressure. The chiller will run up to 100 percent of this setpoint before the Adaptive Control mode reduces capacity.

#### Starter-Contactor Failure Protection

The chiller will protect itself from a starter failure that prevents the compressor motor from disconnecting from the line to the limits of its capabilities.

The controller starts and stops the chiller through the starter. If the starter malfunctions and does not disconnect the compressor motor from the line when requested, the controller will recognize the fault and attempt to protect the chiller by operating the evaporator-and condenser-water pumps and attempting to unload the compressor.

#### Loss of Water-Flow Protection

Tracer AdaptiView<sup>™</sup> control has an input that will accept a contact closure from a proof-of-flow device such as a flow switch or pressure switch. Customer wiring diagrams also suggest that the flow switch be wired in series with the cooling-water (condenser-water) pump starter's auxiliary contacts. When this input does not prove flow within a fixed time during the transition from Stop to Auto modes of the chiller, or if the flow is lost while the chiller is in the Auto mode of operation, the chiller will be inhibited from running by a nonlatching diagnostic.

#### **Evaporator Limit Protection**

Evaporator Limit is a control algorithm that prevents the chiller tripping on its low refrigeranttemperature cutout. The machine may run up to the limit but not trip. Under these conditions the intended chilled-water setpoint may not be met, but the chiller will do as much as it can. The chiller will deliver as much cold water as possible even under adverse conditions.

#### Low Evaporator-Water Temperature

Low evaporator-water temperature protection, also known as Freeze Stat protection, avoids water freezing in the evaporator by immediately shutting down the chiller and attempting to operate the chilled-water pump. This protection is somewhat redundant with the Evaporator Limit protection, and prevents freezing in the event of extreme errors in the evaporator-refrigerant temperature sensor.

The cut out setting should be based on the percentage of antifreeze used in the customer's water loop. The chiller's operation and maintenance documentation provides the necessary information for percent antifreeze and suggests leaving-water temperature-cutout settings for a given chilled-water temperature setpoint.



#### **Oil-Temperature Protection**

Low oil temperature when the oil pump and/or compressor are running may be an indication of refrigerant diluting the oil. If the oil temperature is at or below the low oil-temperature setpoint, the compressor is shut down on a latching diagnostic and cannot be started. The diagnostic is reported at the user interface. The oil heaters are energized in an attempt to raise the oil temperature above the low oil-temperature setpoint.

High oil-temperature protection is used to avoid overheating the oil and the bearings.

#### Low Differential Oil-Pressure Protection

Oil pressure is indicative of oil flow and active oil-pump operation. A significant drop in oil pressure indicates a failure of the oil pump, oil leakage, or a blockage in the oil-circuit.

During Compressor prelube the differential pressure should not fall below 12 psid. Shutdown diagnostic will occure within 2 seconds of the differential pressure falling below two-thirds of the low differential oil-pressure cutout.

#### Phase-Unbalance Protection

Phase-unbalance protection is based on an average of the three phase-current inputs. The ultimate phase-unbalance trip point is 30 percent. In addition, the RLA of the motor is derated by resetting the active current-limit setpoint based on the current unbalance. The RLA derate protection can be disabled in the field-startup menu.

The following derates apply when the phase-unbalance limit is enabled:10% unbalance = 100% RLA derate15% unbalance = 90% RLA derate20% unbalance = 85% RLA derate25% unbalance = 80% RLA derate30% unbalance = Shutdown25% unbalance = 80% RLA derate

#### **Phase-Loss Protection**

The controller will shut down the chiller if any of the three phase currents feeding the motor drop below 10 percent RLA. The shutdown will result in a latching phase-loss diagnostic. The time to trip is 1-3 seconds.

#### Phase Reversal/Rotation Protection

The controller detects reverse phase rotation and provides a latching diagnostic when it is detected. The time to trip is 0.7 seconds.

#### Momentary Power Loss and Distribution Fault Protection

Three-phase momentary power loss (MPL) detection gives the chiller improved performance through many different power anomalies. MPLs of 2.5 cycles or longer will be detected and cause the unit to shut down. The unit will be disconnected from the line within 6 line cycles of detection. If enabled, MPL protection will be active any time the compressor is running. MPL is not active on reduced-voltage starters during startup to avoid nuisance trips. The MPL diagnostic is an automatic reset diagnostic.

An MPL has occurred when the motor no longer consumes power. An MPL may be caused by any drop or sag in the voltage that results in a change in the direction of power flow. Different operating conditions, motor loads, motor size, inlet guide vane (IGV) position, etc. may result in different



levels at which this may occur. It is difficult to define an exact voltage sag or voltage level at which a particular motor will no longer consume power, but we are able to make some general statements concerning MPL protection:

The chiller will remain running under the following conditions:

- Line-voltage sag of 1.5 line cycles or less for any voltage magnitude sag
- Control-voltage sags of less than 3 line cycles for any magnitude sag
- Control-voltage sags of 40 percent or less for any amount of time
- Second-order or lower harmonic content on the line

The chiller may shut down under the following conditions:

- Line-voltage sags of 1.5 or more line cycles for voltage dips of 30 percentor more
- Control-voltage sags of 3 or more line cycles for voltage dips of 40 percentor more
- Third-order or higher harmonic content on the line

#### **Current Overload Protection**

The control panel will monitor the current drawn by each line of the motor and shut the chiller off when the highest of the three line currents exceeds the trip curve. A manual reset diagnostic describing the failure will be displayed. The current overload protection does not prohibit the chiller from reaching its full-load amperage.

The chiller protects itself from damage due to current overload during starting and running modes, but is allowed to reach full-load amps.

#### High Motor-Winding Temperature Protection

This function monitors the motor temperature and terminates chiller operation when the temperature is excessive. The controller monitors each of the three winding-temperature sensors any time the controller is powered up, and displays each of the temperatures at the service menu. Immediately prior to start, and while running, the controller will generate a latching diagnostic if the winding temperature exceeds  $265^{\circ}F(129.4^{\circ}C)$  for 0.5 to 2 seconds.

#### Surge Detection Protection

Surge detection is based on current fluctuations in one of three phases. The default detection criterion is two occurrences of root-man square (RMS) current change of 30 percent within 0.8 seconds in 60 + 10 percent seconds. With the Tracer chiller controller, the detection criterion is adjustable with the Tracer chiller controller.

#### **Overvoltage and Undervoltage Protection**

While some components of the chiller are impervious to dramatically different voltages, the compressor-motor is not. The control panel monitors all three line-to-line voltages for the chiller, and bases the over and undervoltage diagnostics on the average for the three voltages. The default protection resets the unit if the line voltage is below or above  $\pm 10$  percent of the nominal for 60 seconds.

#### Power Factor and kW Measurement

Three-phase measurement of kW and unadjusted power factor yields higher accuracy during power imbalance conditions.



#### **Short-Cycling Protection**

This function mimics heat dissipation from a motor start using two setpoints: Restart Inhibit Free Starts and Restart Inhibit Start-to-Start Timer. This allows the CVGF to inhibit too many starts in a defined amount of time while still allowing for fast restarts. The default for CVGF is 3 Free Starts and a 20 minute Start-to-Start Timer. The control panel generates a warning when the chiller is inhibited from starting by this protection.

#### **Restart Inhibit Free Starts**

This setting will allow a maximum number of rapid restarts equal to its valve. If the number of free starts is set to 1, this will allow only one start within the time period set by the Start-to-Start Time setting. The next Start will be allowed only after the Start-to-Start timer has expired. If the number of free starts is programmed to 3, the control will allow three starts in rapid succession, but thereafter, it would hold off on a compressor start until the Start-to-Start timer expired.

#### Restart Inhibit Start-to-Start Time setting

This setting defines the shortest chiller cycle period possible after the free starts have been used. If the number of free Starts is programmed to 1, and the Start-to-Start Time setting is programmed to 10 minutes. the compressor will be allowed one start every 10 minutes The Start-to-Start time is the time from when the motor was directed to energize to when the next prestart is issued.



50 and 60 Hz SI (English Units)

Figure PD-1 –Model CVGF Cooling Only With Unit-Mounted Starter





Figure PD-2 –Model CVGF Cooling Only Without Unit-Mounted Starter (for Remote-Mounted Starter)

914 mm (36") RECOMMENDED CLEARANCE

HEIGHT



#### Dimensions – SI Units (English Units)

		Clearance Unit Dimensions				Unit Dimensions		
		Tube	Pull	With Unit Mou	inted Starters	Without Unit Mounted Starters		
Comp	Shell Size	CL1	CL2	Length	Height	Width	Width	
400-500	500	4235 mm	1118 mm	4083 mm	2094 mm	1984 mm	1929 mm	
		(13' 10 3/4")	(3' 8")	(13' 4 3/4")	(6' 101/2")	(6' 6 1/8")	(6' 3 15/16")	
500	700	4235 mm	1850 mm	4083 mm	2200 mm	2038 mm	1988 mm	
		13' 10 3/4")	(3' 11")	(13' 4 3/4")	(7' 2 5/8")	(6' 8 1/4")	(6' 6 1/4")	
650	700	4235 mm	1850 mm	4083 mm	2270 mm	2083 mm	2076 mm	
		13' 10 3/4")	(3' 11")	(13' 4 3/4")	(7' 5 3/8")	(6' 10")	(6' 9 3/4")	
800-1000	1000	4235 mm	1219 mm	4083 mm	2521 mm	2305 mm	2257 mm	
		13' 10 3/4")	(4')	(13' 4 3/4")	(8' 3 1/4")	(7' 6 3/4")	(7' 4 7/8")	

CL1 at either end of machine and is required for tube pull clearance.

CL2 is always at the opposite end of machine from CL1 and is for water box plus clearance.

- Recommended clearance (D1) for machine with unit mounted starter is 914 mm (36")

- Recommended clearance (D2) for machine without unit mounted starter is 1219 mm (38")

Unit length is not included for the waterbox.

See page 23 for waterbox dimension



#### Model CVGF Water Connection Pipe Size

		Shell Size	
	500	700	1000
Water Passes		Metric Pipe Size (mm) DN	
Evaporator			
2 Pass	DN 200 (8")	DN 250 (10")	DN 300 (12")
3 Pass	DN 200 (8")	DN 200 (8")	DN 250 (10")
Condenser			
Condenser	DN 250 (10")	DN 300 (12")	DN 350 (14")

#### Evaporator Water Box Length — SI (I-P)

					Length
				No.	mm (in)
Shell	Pressure	Evap.	Passes	Supply	Return
500	10 bar (150 psig)	NMAR	2	402 (15.82)	226 (8.89)
500	10 bar (150 psig)	NMAR	3	402 (15.82)	402 (15.82)
700	10 bar (150 psig)	NMAR	2	489 (19.25)	235 (9.25)
700	10 bar (150 psig)	NMAR	3	438 (17.24)	438 (17.24)
1000	10 bar (150 psig)	NMAR	2	581 (22.87)	276 (10.87)
1000	10 bar (150 psig)	NMAR	3	530 (20.87)	530 (20.87)

#### Condenser Water Box Length — SI (I-P)

					Length
				No.	mm (in)
Shell	Pressure	Evap.	Passes	Supply	Return
500	10 bar (150 psig)	NMAR	2	486 (19.02)	204 (8.03)
700	10 bar (150 psig)	NMAR	2	582 (22.87)	231 (9.09)
1000	10 bar (150 psig)	NMAR	2	658 (25.75)	276 (10.87)



## **Mechanical Specifications**

	Trane CVGF packaged centrifugal water chillers using HFC-134a refrigerant consist of a hermetic two-stage, gear-drive centrifugal compressor, evaporator, condenser, interstage economizer, unit-mounted microprocessor based control panel, and compressor motor starter. The chiller is entire factory assembled.
Compressor	
	Two-stage centrifugal compressor with high-strength aluminum alloy, fully shrouded impellers. The impellers are tested at 25 percent over-design operating speed. The rotating assembly is dynamically balanced for vibration of less than 5.1 mm/s (0.2 ips peak velocities) at nominal operating speeds. The control system affords and admitted 100 - 20 percent capacity modulation by electrically actuated guide vanes upstream of each impeller.
Drive Train	
	The drive train consists of helical bull and pinion gears. Gear tooth surfaces are case hardened and precision ground. The one-piece impeller shaft is supported by hydrodynamic thrust and radial bearings.
Motor	
	The motor is a hermetic, liquid-refrigerant cooled, two-pole, low-slip, squirrel-cage induction motor. A radial hydrodynamic bearing and duplex angular contact ball bearings support the rotor assembly. Winding-embedded sensors provide positive thermal protection.
Lubrication System	
	The lubrication system consists of an internal oil sump with heaters, positive displacement oil pump, brazed plate condenser-cooled oil cooler, and oil distillation/return line.
Economizer/Orifice	
	The economizer consists of a carbon steel shell with internal components designed to prevent liquid carryover to the compressor. Liquid refrigerant is admitted through a single calibrated orifice (no moving parts) which maintains a pressure differential between condenser and economizer.
Evaporator	
	The evaporator is designed, tested and stamped in accordance with ASME Boiler and Pressure Vessel Code or PED (European Code) for refrigerant side working pressure of 15.2 bars (220psig). It consists of a carbon steel shell with steel tube sheets welded to eachend. Intermediate tube support sheets positioned along the shell axis prevent relative tube motion. Individually-replaceable externally-finned and internally-grooved 19 mm (¾ in.) and 25.4 mm (1.0 in.) nominal diameter seamless copper tubes are mechanically expanded into tube sheets.
	Two- or three- pass water boxes rated at 10.5 bar (150 psi) is standard. Grooved pipe connections are standard; flanged connections are optionally available. The waterside is hydrostatically tested at ASME 1.5 times, PED 1.43 times, GB 1.25 times maximum working pressure.
	Liquid refrigerant is admitted to the evaporator through a single calibrated orifice (no moving parts) which maintains a pressure differential between the economizer and the evaporator.



#### **Mechanical Specifications**

#### Condenser

The condenser is designed, tested and stamped in accordance with the ASME Boiler and Pressure Vessel Code or PED (European Code) for a refrigerant side working pressure of 15.2 bars (220 psig). It consists of a carbon steel shell with steel tube sheets welded to each end. Individually-replaceable, externally-finned and internally-grooved 19 mm(<sup>3</sup>/<sub>4</sub> in.) and 25.4 mm (1.0 in.) nominal diameter seamless copper tubes are mechanically expanded into the tubesheets.

Two-pass water boxes are bolted to the tube sheets. Grooved pipe connections are standard. flanged connections are optionally available. Maximum waterside working pressureof 10.5 bars (150 psi) is standard. The waterside is hydrostatically tested at ASME 1.5 times, PED 1.43 times, GB 1.25 times maximum working pressure.

#### **Unit Control Panel**

The microcomputer control panel is factory installed and tested on the CVGF unit. All controls necessary for the safe and reliable operation of the chiller are provided including oil management, interface to the starter, and three phase motor overload protection. It also includes comprehensive status and diagnostic monitoring controls. A control power transformer included in the starter panel powers the control system.

The microprocessor controller is compatible with reduced voltage or full voltage electro-mechanical starters, and solid state starter. Starter for Europe with the CE mark is available.

The microcomputer control system processes the leaving evaporator fluid temperature sensor signal to satisfy the system requirements across the entire load range.

The controller will load and unload the chiller via control of the stepper- motor/actuator which drives the inlet guide vanes open and closed. The load range can be limited either by a control limitor or by an inlet guide vane limit (whichever controls the lower limit). It will also control the evaporator and condenser pumps to insure proper chiller operation.

Status and 10 active diagnostics are communicated to the operator via display with a tabbed navigation system. Setpoints are entered through the touch-sensitive screen. Countdown timer displays remaining time(s) during wait states and time out periods. Non-volatile memory saves unit set-up information during power loss without the need for batteries. Password protection is provided to secure the operator interface. PC-based service tool software displays the last 60 active or 60 historic diagnostics, indicating the time, date of occurrence, and system parameters at the time of the diagnostic.

The service tool provides advanced troubleshooting and access to sophisticated configuration settings not needed during operation of the chiller. Any PC that meets the installation requirements may be loaded with the service tool software via download from www.trane.com.

Unit mounted display is capable of displaying chiller parameters in IP or SI units, and language in English and any 2 downloadable and/or locally translated languages.



#### **Mechanical Specifications**

#### **Compressor-Motor Starter**

Unit-mounted starters can either be a star-delta or solid-state in NEMA 1 type enclosure rated up
to 952 RLA at 380-480 Volts (star-delta), 900 RLA at 481-600 Volts (star-delta), and 1472 RLA at
380-600 Volts (solid-state).

Remote-mounted starters can either be star-delta or solid-state for low voltage. Across-the-line, primary reactor, or autotransformer for medium and high voltage. All in NEMA 1 type enclosures up to 1402 RLA at 380-600 volts (star-delta), 1472 RLA at 380-600 Volts (solid-state), and 360 RLA at 3300-6600 Volts (x-line, primary reactor, and autotransformer).

Unit-mounted or remote-mounted starters for Europe (CE mark) will be star-delta, solid-state, across-the-line, primary reactor, and autotransformer only in a IP 10 enclosure.

A steel panel door with optional mechanical interlock disconnects the system when the door is opened (required for CE listing). The panel also contains three-phase current transformer for overload protection, and an oil pump starter with overloads. The starter is factory mounted and wired to the compressor motor and the control panel. The CVGF chiller/starter assembly is factory tested.

Optional remote-mounted electromechanical starters are available.

#### **Isolation Pads**

Molded neoprene isolation pads are supplied with each chiller for placement under all support points. Spring isolators are optionally available.

#### **Refrigerant and Oil Charge**

A full charge of oil is supplied with each unit. The oil ships in the unit's sump and the refrigerant
ships directly to the job site from refrigerant suppliers.

All painted CVGF surfaces are coated with two coats of air-dry, beige primer-finisher prior to shipment.

Insulation

Painting

The chiller can be ordered with or without factory-applied insulation. Factory-supplied insulation is applied to all low temperature surfaces including the evaporator, water boxes and suction elbow. Insulation material is 19mm ( $\frac{3}{4}$  in.) Armaflex II or equal (thermal conductivity = 0.04 W/m·°C; 0.3 Btu·in/h·ft<sup>2</sup>·°F). The oil sump is covered with 9.5 mm ( $\frac{3}{8}$  in.) and 13 mm ( $\frac{1}{2}$  in.) insulation.

Rigging

Evaporator and condenser tube sheets provide rigging support points. A rigging diagram is affixed to the chiller.

#### Quality

The chiller manufacturing facility is ISO 9001 certified.



## **Conversion Table**

To Convert From:	To :	Multiply By:	To Convert From:	To :	Multiply By:			
Length			Energy and Power and Capa	icity				
Feet (ft)	meters(mm)	0.30481	British Thermal Units (Btu/h)	Kilowatt (kW)	0.000293			
Inches (In)	millimeters (mm)	25.4	British Thermal Units (Btu)	KCalorie (Kcal)	0.252			
Area			Tons (refrig. effect)	Kilowatt (refrig. effect)	3.516			
Square Feet (ft <sup>2</sup> )	square meters (m <sup>2</sup> )	0.093	Tons (refrig. effect)	Kilocalories per hour (Kcal/hr)	3024			
Square Inches (In <sup>2</sup> )	square millimeters (mm²)	645.2	Horsepower	Kilowatt (kW)	0.7457			
Volume								
Cubic Feet (ft <sup>2</sup> )	Cubic meters (m <sup>3</sup> )	0.0283	Pressure					
Cubic Inches (In <sup>3</sup> )	Cubic mm (mm <sup>3</sup> )	16387	Feet of water (ftH <sub>2</sub> 0)	Pascals (pa)	2990			
Gallons (gal)	litres (L)	3.875	Inches of water (inH <sub>2</sub> 0)	Pascals (pa)	249			
Gallons (gal)	cubic meters (m <sup>3</sup> )	0.003785	Pounds per square inch (psi)	Pascals (pa)	6895			
Flow			PSI	Bar or kg/cm <sup>2</sup>	6.895 x 10 <sup>-2</sup>			
Cubic feet/min (cfm)	cubic meters/second (m <sup>3</sup> /s)	0.000472	Weight					
Cubic Feet/min (cfm)	cubic metrs/hr (m³/hour)	1.69884	Ounches (oz)	Kilograms (kg)	0.02835			
Gallons/minute (gpm)	cubic meters/hr (m³/hour)	0.2271	Pounds (lbs)	Kilograms (kg)	0.4536			
Gallons/minute (gpm)	litres/second (l/s)	0.06308	Fouling factors for heat exchangers					
Velocity			0.00075 ft <sup>2</sup> °F hr/Btu	=0.132 m <sup>2</sup> ° K/kW				
Feet per minute (ft/m)	meters per second (m/s)	0.00508	0.00025 ft <sup>2</sup> °F hr/Btu	=0.044 m <sup>2</sup> ° K/kW				
Feet per second (ft/s)	meters per second (m/s)	0.3048						

Temperature-Centigrade (°C) versus Fahrenheit (°F) Note: The center columns of numbers, referred to as BASE TEMP, is the temperature in either degrees Fahrenheit (°F) or Centigrade (°C), whichever is desired to convert into the other. If degrees Centrigrade is given, read degrees Fahrenheit to the right. If degrees Fahrenheit is given, read degrees Centigrade to the left.

Temperature		Temperature		Temperature			257.0Temperature				Temperature						
°C	C or F	°F	F	°C	C or F	°F		°C	C or F	°F	°C	C or F	°F		°C	C or F	°F
-40.0 -39.4 -38.9 -38.3 -37.8	-40 -39 -38 -37 -36	-40 -38.2 -36.4 -34.6 -32.8	-	-15.0 -14.4 -13.9 -13.3 -12.8	+5 +6 +7 +8 +9	+41.0 +42.8 +44.6 +46.4 +48.2	-	+10.0 +10.6 +11.1 +11.7 +12.2	+50 +51 +52 +53 +54	+122.0 +123.8 +125.6 +127.4 +129.2	+35.0 +35.6 +36.1 +36.7 +37.2	+95 +96 +97 +98 +99	+203.0 +204.8 +206.6 +208.4 +210.2		+60.0 +60.6 +61.1 +61.7 +62.2	+140 +141 +142 +143 +144	+284.0 +285.8 +287.6 +289.4 +291.2
-37.2 -36.7 -36.1 -35.6 -35.0	-35 -34 -33 -32 -31	-31.0 -29.2 -27.4 -25.6 -23.8		-12.2 -11.7 -11.1 -10.6 -10.0	+10 +11 +12 +13 +14	+50.0 +51.8 +53.6 +55.4 +57.2		+12.8 +13.3 +13.9 +14.4 +15.0	+55 +56 +57 +58 +59	+131.0 +132.8 +134.6 +136.4 +138.2	+37.8 +38.3 +38.9 +39.4 +40.0	+100 +101 +102 +103 +104	+212.0 +213.8 +215.6 +217.4 +219.2		+62.8 +63.3 +63.9 +64.4 +65.0	+145 +146 +147 +148 +149	+293.0 +294.8 +296.6 +298.4 +300.2
-34.4 -33.9 -33.3 -32.8 -32.2	-30 -29 -28 -27 -26	-22.0 -20.2 -18.4 -16.6 -14.8		-9.4 -8.9 -8.3 -7.8 -7.2	+15 +16 +17 +18 +19	+59.0 +60.8 +62.6 +64.4 +66.2		+15.6 +16.1 +16.7 +17.2 +17.8	+60 +61 +62 +63 +64	+140.0 +141.8 +143.6 +145.4 +147.2	+40.6 +41.1 +41.7 +42.2 +42.8	+105 +106 +107 +108 +109	+221.0 +222.8 +224.6 +226.4 +228.2		+65.6 +66.1 +66.7 +67.2 +67.8	+150 +151 +152 +153 +154	+302.0 +303.8 +305.6 +307.4 +309.2
-31.7 -31.1 -30.6 -30.0 -29.4	-25 -24 -23 -22 -21	-13.0 -11.2 -9.4 -7.6 -5.8		-6.7 -6.1 -5.5 -5.0 -4.4	+20 +21 +22 +23 +24	+68.0 +69.8 +71.6 +73.4 +75.2		+18.3 +18.9 +19.4 +20.0 +20.6	+65 +66 +67 +68 +69	+149.0 +150.8 +152.6 +154.4 +156.2	+43.3 +43.9 +44.4 +45.0 +45.6	+110 +111 +112 +113 +114	+230.0 +231.8 +233.6 +235.4 +237.2		+68.3 +68.9 +69.4 +70.0 +70.6	+155 +156 +157 +158 +159	+311.0 +312.8 +314.6 +316.4 +318.2
-28.9 -28.3 -27.8 -27.2 -26.7	-20 -19 -18 -17 -16	-4.0 -2.2 -0.4 +1.4 +3.2		-3.9 -3.3 -2.8 -2.2 -1.7	+25 +26 +27 +28 +29	+77.0 +78.8 +80.6 +82.4 +84.2		+21.1 +21.7 +22.2 +22.8 +23.2	+70 +71 +72 +73 +74	+158.0 +159.8 +161.6 +163.4 +165.2	+46.1 +46.1 +47.2 +47.8 +48.3	+115 +116 +117 +118 +119	+239.0 +240.8 +242.6 +244.4 +246.2		+71.1 +71.7 +72.2 +72.8 +73.3	+160 +161 +162 +163 +164	+320.0 +321.8 +323.6 +325.4 +327.2
-26.1 -25.6 -25.0 -24.4 -23.9	-15 -14 -13 -12 -11	+5.0 +6.8 +8.6 +10.4+ +12.2		-1.1 -0.6 0.0 +0.6 +1.1	+30 +31 +32 +33 +34	+86.0 +87.8 +89.6 +91.4 +93.2		+23.9 +24.4 +25.0 +25.6 +26.1	+75 +76 +77 +78 +79	+167.0 +168.8 +170.6 +172.4 +174.2	+48.9 +49.4 +50.0 +50.6 +51.1	+120 +121 +122 +123 +124	+248.0 +249.8 +251.6 +253.4 +255.2		+73.9 +74.4 +75.0 +75.6 +76.1	+165 +166 +167 +168 +169	+329.0 +330.8 +332.6 +334.4 +336.2
-23.3 -22.8 -22.2 -21.7 -21.1	-10 -9 -8 -7 -6	+14.0 +15.8 +17.6 +19.4 +21.2		+1.7 +2.2 +2.8 +3.3+ 3.9	+35 +36 +37 +38 +39	+95.0 +96.8 +98.6 +100.4 +102.2		+26.7 +27.2 +27.8 +28.3 +28.9	+80 +81 +82 +83 +84	+176.0 +177.8 +179.6 +181.4 +183.2	+51.7 +52.2 +52.8 +53.3 +53.9	+125 +126 +127 +128 +129	+257.0 +258.8 +260.5 +262.4 +264.2		+76.7 +77.2 +77.8 +78.3 +78.9	+170 +171 +172 +173 +174	+338.0 +339.8 +341.6 +343.4 +345.2
-20.6 -20.0 -19.4 -18.9 -18.3	-5 -4 -3 -2 -1	+23.0 +24.8 +26.6 +28.4 +30.2		+4.4 +5.0 +5.5 +6.1 +6.7	+40 +41 +42 +43 +44	+104.0 +105.8 +107.6 +109.4 +111.2		+29.4 +30.0 +30.6 +31.1 +31.7	+85 +86 +87 +88 +89	+185.0 +186.8 +188.6 +199.4 +192.2	+54.4 +55.0 +55.6 +56.1 +56.7	+130 +131 +132 +133 +134	+266.0 +257.8 +269.6 +271.4 +273.2		+79.4 +80.0 +80.6 +81.1 +81.7	+175 +176 +177 +178 +179	+347.0 +348.8 +350.6 +352.4 +354.2
-17.8 -17.2 -16.7 -16.1 -15.6	0 +1 +2 +3 +4	+32.0 +33.8 +35.6 +37.4 +39.2		+7.2 +7.8 +8.3 +8.9 +9.4	+45 +46 +47 +48 +49	+113.0 +114.8 +116.6 +118.4 +120.2		+32.2 +32.8 +33.3 +33.9 +34.4	+90 +91 +92 +93 +94	+194.0 +195.8 +197.6 +199.4 +201.2	+57.2 +57.8 +58.3 +58.9 +59.4	+135 +136 +137 +138 +139	+275.0 +276.8 +278.6 +280.4 +282.2		+82.2 +82.8 +83.3 +83.9 +84.4	+180 +181 +182 +183 +184	+356.0 +357.8 +359.8 +361.4 +363.2
								5.56 18.0									



# Literature Order Number CTV-PRC001-E4 Date October 2008 Supersedes September 2004

#### www.trane.com

For more information, contact your local Trane office or e-mail us at comfort@trane.com

Trane has a policy of continuous product and data improvement and reserves the right to change design specifications without notice.